



HIKVISION[®]

2016

How to Setup Email on Hikvision NVR & DVR


How to Setup Email -NVR or DVR

- **E-mail** is an action that can be taken by the NVR or DVR to alert a user of an event or alarm of a specified type.
- **In order to Send Email**, the NVR or DVR network settings need to be configured with a correct IP address, subnet mask, default gateway and DNS server.

NOTE: Please see the quick start guide or how to set NVR \ DVR network settings.

How to Setup Email –NVR or DVR


- From the main menu select System Configuration.
- The system configuration menu is where to set the date and time, configure the network setting, change port numbers, enable DDNS settings, setup email, users accounts and more.



NOTE: Right clicking anywhere on the live view screen and select main menu.


How to Setup Email –NVR or DVR

- Select the Network Menu^[1] from the left, click on the Email tab^[2] along the top.



How to Setup Email –NVR or DVR

- Place a check in the Enable Server Authentication box^[3].



General DDNS **Email** SNMP NAT More Settings

Enable Server Authentication 3

User Name youremail@gmail.com 4

Password *****

- Input your username and password for the email account being used^[4]. This will be the account sending the emails.

NOTE: A Gmail Email account is used as the example. Please refer to your email service for specific requirements.

How to Setup Email –NVR or DVR

- Input the correct SMTP Server,^[5] Port number^[6] and enable\disable SSL settings.^[7]

SMTP	
SMTP Server	smtp.gmail.com ⁵
SMTP Port	465 ⁶
Enable SSL	<input checked="" type="checkbox"/> ⁷

- You can search the internet for public email service SMTP servers and ports. You may also need to contact your system administrator if using a company emailserver.
- SSL(port 465) and TLS (port 587) are two encryption types supported by the DVR and NVR with the most updated version of firmware.

NOTE: A Gmail Email account is used as the example. Please refer to your email service for specific requirements.
Not all NVR and DVRs support TLS.

How to Setup Email –NVR or DVR

- Input the Sender Name^[8] and Email Address.^[9] It is recommended that the sender's address matches the email address or account used for authentication (refer to step 4).

Sender	
Sender Name	Your Name Here 8
Sender's Address	youremail@gmail.com 9


- Click the edit icon^[10] to Input up to three recipients for the emails.

Receiver				
No.	Edit	Name	Address	Delete
1	 10	Business Owner	businessowner@email.com	
2		System Administrator	sysadmin@email.com	
3				

NOTE: A Gmail Email account is used as the example. Please refer to your email service for specific requirements.

How to Setup Email –NVR or DVR

- Enable Attached Picture will include three .jpeg images in the Email.



Enable Attached Picture	<input checked="" type="checkbox"/>
Interval	2s

Note: The interval will be the number of seconds between the images. For example: 2s before the event, the event, and 2s after the event.

- Enable Email Interval will delay the time between the sending of emails.



Enable Email Interval	<input checked="" type="checkbox"/>
Email Interval	5Min

Note: The interval is designed to limit the amount of emails sent to a user. For example: If an email is sent on channel 1 from a motion detection event, channel 1 will not send an email for the next 5 min even if another event triggers.

Troubleshooting How to Setup Email

- The NVR or DVR may require a public DNS server. Searching the internet for public DNS servers will be the best way to find one. For example, these addresses are public DNS servers: 8.8.8.8 or 4.2.2.2 or 75.75.75.75
- Make sure to have the most updated firmware versions that support SSL and TLS encryption.
- Make sure to click Apply before clicking the test button. These buttons are located in the bottom left corner of the menu.

